



# S-XP-G55VC Parts List

XP-No	Item No.	Part Describe	Quantity	XP-No	Item No.	Part Describe	Quantity
XP-G55VC-1	1	Hammer rod protector	1	XP-G55VC-50	50	ST4.2x18 Tapping Screw	4
XP-G55VC-2	2	Protective lining	1	XP-G55VC-52	52	Main Handle Cover	1
XP-G55VC-3	3	Φ30 Retaining Ring	1	XP-G55VC-54	54	Indicator	1
XP-G55VC-4	4	Support patch	1	XP-G55VC-55	55	Main Handle	1
XP-G55VC-5	5	Shock absorption ring	1	XP-G55VC-56	56	ST5.5x45 Tapping Screw	2
XP-G55VC-6	6	Move limited ring	1	XP-G55VC-57	57	ST4.2x22 Tapping Screw	3
XP-G55VC-7	7	Insert block	2	XP-G55VC-58	58	Cord Armor	1
XP-G55VC-8	8	Change plate	1	XP-G55VC-59	59	Cord	1
XP-G55VC-9	9	Support ring spring	1	XP-G55VC-60	60	0.18μH Electricity Feels	1
XP-G55VC-10	10	Support ring	1	XP-G55VC-61	61	Rivet	4
XP-G55VC-11	11	Move limited ring	1	XP-G55VC-62	62	Stator 220-240V	1
XP-G55VC-12	12	Φ6.5 Steel Ball	8	XP-G55VC-62	62	Stator 110-120V	1
XP-G55VC-13	13	Hex. Socket Bolt M8x30(12.9)	4	XP-G55VC-63	63	ST4.8x58 Tapping Screw	2
XP-G55VC-13A	13A	Φ8 Spring Washer	4	XP-G55VC-64	64	Carbon Brush bracket	1
XP-G55VC-14	14	Flange cover	1	XP-G55VC-65	65	Helical spring	2
XP-G55VC-15	15	O-RingΦ63.5xΦ2.6	1	XP-G55VC-66	66	Metal contact plate	1
XP-G55VC-16	16	Hammer rod sleeve	1	XP-G55VC-67	67	Cross recessed pan head screws S	5
XP-G55VC-17	17	Fluorin O Ring Φ31.6xΦ2.5	1	XP-G55VC-68	68	Metal insert	2
XP-G55VC-18	18	Φ41 Retaining Ring	2	XP-G55VC-69	69	Carbon Brush	2
XP-G55VC-19	19	Oil Seal Ring Φ32xΦ42x7	1	XP-G55VC-70	70	Carbon brush wire	2
XP-G55VC-20	20	Impact Pin	1	XP-G55VC-72	72	Armature 220-240V	1
XP-G55VC-21	21	Fluorin O RingΦ22xΦ11	1	XP-G55VC-72	72	Armature 110-120V	1
XP-G55VC-22	22	Control plate	1	XP-G55VC-73	73	Bearing Sleeve	1
XP-G55VC-23	23	Fixed Distance Sleeve	1	XP-G55VC-74	74	6200 DD Ball Bearing	1
XP-G55VC-24	24	O-RingΦ35xΦ3	1	XP-G55VC-74A	74A	Φ10 Retaining Ring	1
XP-G55VC-25	25	Impact block	1	XP-G55VC-75	75	O-Ring Φ30xΦ2	1
XP-G55VC-26	26	Fluorin O RingΦ30.4xΦ5	2	XP-G55VC-76	76	Screw ring	1
XP-G55VC-27	27	Cover	1	XP-G55VC-77	77	Protected cover	1
XP-G55VC-28	28	Control Sleeve	1	XP-G55VC-78	78	Bearing Cover	1
XP-G55VC-29	29	Control Sleeve Spring	1	XP-G55VC-79	79	Tapping screw ST5.5X25	8
XP-G55VC-30	30	Cylinder	1	XP-G55VC-80	80	Disk with gap	2
XP-G55VC-31	31	Piston Pin Φ10x38	1	XP-G55VC-81	81	Clamping	2
XP-G55VC-32	32	Piston	1	XP-G55VC-82	82	Fixed belt	1
XP-G55VC-33	33	Connecting Rod Ass'y	1	XP-G55VC-83	83	Hexagon head bolt M8x130	1
XP-G55VC-34	34	Impact body	1	XP-G55VC-84	84	Side Handle	1
XP-G55VC-35	35	Tapping screw ST6.3X32	4	XP-G55VC-85	85	Function Knob	1
XP-G55VC-36	36	Oil Tank Cover	1	XP-G55VC-86	86	Nut M8(Thickness 6.4mm)	1
XP-G55VC-37	37	Rubber Washer Φ31xΦ25x2.2	1	XP-G55VC-87	87	Function Knob cover	1
XP-G55VC-38	38	Felt Ring	1	XP-G55VC-88	88	10mm Hex Bar Wrench	1
XP-G55VC-39	39	Hex .Socket Bolt M5x12 (12.9)	4	XP-G55VC-91	91	Oil BottleΦ35x135	1
XP-G55VC-40	40	Shell cover	1	XP-G55VC-92	92	Fixed Platen	1
XP-G55VC-41	41	O-RingΦ79xΦ2.8	1	XP-G55VC-93	93	Main Handle Seat	1
XP-G55VC-42	42	Eccentric gear subassembl	1	XP-G55VC-94	94	Shock Absorption Jacket	1
XP-G55VC-43	43	6002 DD Ball Bearing	1	XP-G55VC-95	95	Shock Absorption Ferrule	2
XP-G55VC-44	44	Distance Ring	1	XP-G55VC-96	96	Shock Absorption Spring	1
XP-G55VC-45	45	6002 RS Ball Bearing	1	XP-G55VC-97	97	Spring Rack	1
XP-G55VC-46	46	Needle Bearing NK20x28x13	1	XP-G55VC-98	98	Cross recessed pan head screws M	2
XP-G55VC-47	47	Seal ring subassembly	2	XP-G55VC-99	99	O-RingΦ16xΦ3	2
XP-G55VC-48	48	Housing Ass'y	1	XP-G55VC-101	101	Speed Adjuster	1
XP-G55VC-49	49	Cord Clip	1	XP-G55VC-102	102	Switch Subassembly	1

